



CASHMAN



2,000 HOUR PLANNED PREVENTATIVE MAINTENANCE*

Engine oil & filter
Engine crankcase breather
Engine air filters
Intake & exhaust system
Fan & alternator belts
Lubricate machine
Radiator

Cooling system
Transmission & Differential housings
Hydraulic system
Hydraulic tank
Gear oil compartments
Fuel tank
Air reservoir
Seat belt
Alarms, indicators, & gauges
Back-up alarm & lights
Tires
Brake system
Batteries, cables, & terminals
Air conditioning
Ground engaging tools (GET) & undercarriage
Hydraulic Cylinders
Glass, doors, latches, & body panels
Machine operation
Fluid Analysis of all oil compartments & coolant

Change
 Inspect & clean
 Inspect & clean primary, change secondary filter
 Visual check for leaks
 Inspect & adjust if necessary
 Service all grease fittings
 Change antifreeze except when coolant is ELC
 When ELC add ELC extender @ 3,000 Hr intervals
 When ELC change ELC coolant @ 6,000 Hr intervals
 Inspect for leaks & fill if necessary
 Check oil level & fill if necessary
 Check for leaks & fill if necessary
 Change oil & filter
 Change oils
 Drain moisture & sediment, inspect for leaks
 Drain moisture & sediment, inspect for leaks
 Inspect for damage or expiration
 Verify operation
 Verify operation
 Check inflation pressure & fill if necessary
 Check operation & fill fluid level if necessary
 Inspect & fill if necessary
 Verify operation & clean cab filters
 Visually inspect
 Inspect for leaks or damage
 Inspect for damage
 Operational performance check

**Actual preventative maintenance services performed vary based on model.
 Please consult a technician or a product support representative at 1.800.937.2326 for more information.*